





Pictured Metal bar for bottom discharge flexi bag placement. For top discharge bags, the bottom bar should sit 2 inches from floor, or on bracket at groove.



Cable tied top after lockdown for top and bottom, lower bar with warning stickers. To discourage left door opening when container is loaded.



Center bar to stop metal bat from bending on pressure, Should be place in a way that the left door close on it. As In picture 14





## Things to note



Center bar to stop metal bar from bending on pressure, Should be place in a way that the left door close on it. As In picture 14



Relief Valve. Some bags comes with relief valve, To relief air, open by twisting midway but always remember to close it after loading. When full load is achieved the product can be seen Thru the transparent tube. Roll up and tie firm to avoid the tube from swaying on transit. As in picture.



Make sure the container wall is good without sharp edges, and the floor is in good grade without splinters or Protruding nails and screws that can damage the bags. Insist from your forwarder to get grade A container.

